



REGISTERING YOUR WAREHOUSE GATEWAY

HOW TO REGISTER YOUR WAREHOUSE GATEWAY

1. Log on to our website useDryLINK.com.
2. Go to the settings section in the web portal
3. Click on “Gateways & Locations”
4. Scroll down to and click on “Add New Gateway”
5. Enter the name of the warehouse
6. Enter the UUID of the warehouse gateway
7. Select “Warehouse” from the drop down menu
8. Select the warehouse name
9. Scroll to the bottom and click “Save Changes”

The screenshot displays the Phoenix web portal interface. At the top, the navigation bar includes 'PHOENIX', 'JOBS (2)', 'EQUIPMENT (34)', 'ASSET MANAGER', and 'ENTERPRISE ^'. On the right, there is a 'Settings' gear icon, a user profile 'KH Keith Hosli', and a 'Sign Out' link. The main content area is titled 'SETTINGS' and contains several tabs: 'My Settings', 'Job Management Alerts', 'Automation', 'Team', 'Gateways & Locations' (highlighted in red), 'Labels', 'Company Profile', 'Integrations', and 'Subscriptions'. Below the tabs, there are sections for 'Warehouse(s) (1)' and 'Gateway(s) (1)'. The 'Warehouse(s) (1)' section has a table with columns for Warehouse Name, Street Address, City, State, and Zip Code. A row shows 'Tudor Warehouse' with address '10316 Tudor Ln', city 'River Ridge', state 'LA', and zip '70123'. Below this is a '+ ADD NEW WAREHOUSE' button. The 'Gateway(s) (1)' section has a table with columns for Gateway Name, UUID, Type, Location Coordinates, Status, and Last Read Time. A row shows 'Gateway' with a 'UUID' field, a 'Stand...' dropdown menu, and '0.0' for location coordinates. Below this is a '+ ADD NEW GATEWAY' button. At the bottom, there is a 'DryPhone(s) (5)' section and two buttons: 'SAVE CHANGES' and 'CANCEL'.